



NOTES:

PRIMER OPTIONAL (NOT SHOWN)

DETAIL TO ACCOMMODATE 25% MOVEMENT.

APPLY 1/2-INCH X 1/2-INCH CANT STRIP.

APPLY BOND BREAKER TAPE BEFORE THE APPLICATION OF CIM A MINIMUM 6-INCHES UP VERTICAL AND ALONG HORIZONTAL SUBSTRATE.

REFER TO MANUFACTURES INSTRUCTION GUIDES FOR MORE DETAILED INFORMATION.



C.I.M. Industries Inc.
23 Elm Street
Peterborough, NH 03458
www.cimindustries.com
603-924-9481

DATE
 09.09.02
 SCALE
 NTS

CIM 02-022
 PROJECT:
 CIM - INDUSTRIES
 TITLE: CIM 800, 1000, 1061
 CONSTRUCTION JOINT CORNER DETAIL