



NOTES:

PRIME OPTIONAL (NOT SHOWN).

DETAIL TO ACCOMMODATE MAXIMUM OF 25% TOTAL MOVEMENT.

BACKER ROD SHOULD BE PLACED AT A DEPTH OF NO MORE THAN 1/2-INCH DEEP.

APPLY CIM IN JOINT. LET CURE A MINIMUM OF 12 HOURS.

APPLY BOND BREAKER TAPE OVER SEALANT.

APPLY CIM TOPCOAT OVER TOP OF BOND BREAKER TAPE AND EXTEND BEYOND JOINT FACES A MINIMUM OF 2-INCHES.



C.I.M. Industries Inc.
 23 Elm Street
 Peterborough, NH 03458
 www.cimindustries.com
 603-924-9481

DATE	CIM 02-0019
09.09.02	PROJECT: C.I.M. INDUSTRIES INC.
SCALE NTS	TITLE: CIM 800, 1000, 1061 EXPANSION JOINT DETAIL